Ultimate DIY Trail Shoe Care – Quick Guide

	Hand-Wash Protocol
	Lukewarm water & gentle soap
	☐ Brush lightly, no machine
	Air dry in shade
•	DIY Anti-Odor Inserts
	☐ Baking soda in sock
	Cedar-charcoal pouch
	Zeolite insert
	Outsole Lug Patch
	☐ Materials: patch, glue, clamp
	☐ Cut patch to size
	☐ Prep, glue & clamp
	☐ Trim & finish
•	DWR Spray Waterproofing
	☐ Clean & mask areas
	☐ Spray evenly
	☐ Wait 10 min
	Heat-activate with hair dryer
••	Rotation, Storage & Foam Testing
	Store cool & dry, upright
	☐ Rotate shoes regularly
	☐ Check compression threshold